


SOHODESK SD01

ASSEMBLY INSTRUCTIONS - PLEASE KEEP FOR FUTURE REFERENCE

HOME OFFICE FURNITURE



Dimensions

Length - 120 cm

Depth - 48 cm

Height - 77 cm

Weight - ---- kg

Maximum Weight Tolerance
50kg

IMPORTANT - PLEASE READ THE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY

SAFETY AND CARE ADVICE

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product during assembly, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use the allen key provided, or a hand screwdriver.
- Dispose of all packaging carefully and responsibly.



Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- Do not stand on the unit.
- Do not use this unit as a step ladder.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.










Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

COMPONENTS - FIXINGS

PLEASE CHECK YOU HAVE ALL THE PARTS LISTED BELOW


Note : The quantities below are the correct amount to complete the assembly.
In some cases more fittings may be supplied than are required.

<p>A</p>  <p>Size M6 x 35 Bolt x 16</p>	<p>B</p>  <p>Minifix Cam x 16</p>	<p>C</p>  <p>Minifix Bolt x 16</p>
<p>D</p>  <p>Size M6 x 20 Bolt x 4</p>	<p>E</p>  <p>Size M6 x 25 Bolt x 4</p>	<p>F</p>  <p>Size M6 x 12 Allen Head Nut x 4</p>
<p>G</p>  <p>Puller Nut 10 x 13 x 16</p>	<p>H</p>  <p>Size 3,5 x 13 Screw x 16</p>	<p>I</p>  <p>Height Adjustable Foot x 4 (Size M6 x 25 mm)</p>


Tools required



Phillips screwdriver



Small hammer




Tape measure

COMPONENTS - FIXINGS

PLEASE CHECK YOU HAVE ALL THE PARTS LISTED BELOW


Note : The quantities below are the correct amount to complete the assembly.
In some cases more fittings may be supplied than are required.

J



Accuride Runners
x 4

K




Plastic corner piece
x 2


Tools required



Phillips screwdriver




Small hammer




Tape measure

COMPONENTS - PARTS


PLEASE CHECK YOU HAVE ALL THE PARTS LISTED BELOW




1 Desktop




2 Side of cabinet x 2




3 Bottom of cabinet




4 Back of cabinet




5 Front of drawer x 2




6 Drawer side x 4




7 Drawer back cover x 2




8 Back of drawer x 2




9 Bottom of drawer x 2




10 Left leg



11 Right leg



12 Beam x 2







13 Connect bar

Step 1

ASSEMBLY INSTRUCTIONS


Screw in adjustable feet **I** onto left leg **10** and right leg **11**.



Step 2

Use beam **12** to connect left leg **10** and right leg **11** by using bolts **A**.


Use connect bar **13** to connect left leg **10** and right leg **11** by using bolts **D** and cap nut **F**.




Step 3

ASSEMBLY INSTRUCTIONS

Separate the accurate runners (J) as shown in image J1 and J2.




Use screw (H) to fix the runners J1 to the inside of the cabinet side panels 2.



Step 4

Add all Minifix cams (B) into the cabinet panels 2 and 4. Note the arrow on the cam must point to the nearest edge of the wood panel in order to accept the bolt.

Screw the Minifix bolts (C) into the cabinet panels 2, before fixing all cabinet panels together.




Step 5

ASSEMBLY INSTRUCTIONS


Connect minifix bolts (C) to the bottom cabinet 3.

Fix the bottom of cabinet 3 to the cabinet sides 2.



Step 6

Fix the cabinet to the metal frame by using M6 x 35mm (A) bolts.




Step 7

ASSEMBLY INSTRUCTIONS

Fix the puller nuts **G** to the drawer back **8**.


Start the drawer assembly with the part number **8**, fix drawer sides **4** by using M6 x 35mm **A** bolts.

And then connect the drawer bottom **9**.



Step 8


After the drawer assembly, install the drawer rails by using 3,5 x 13 **H** screws.



Step 9


ASSEMBLY INSTRUCTIONS

Please the assembled drawer onto the rails.





Step 10



Fix the drawer front **5** by using plastic corner pieces provided with M6 x 25mm **E** screws.



BOTTOM DRAWER
STEP 1




TOP DRAWER
STEP 2



Step 11


ASSEMBLY INSTRUCTIONS

Remove the upper drawer by pressing the upper drawer latch before fixing the desktop **1**.



Step 12


Fix the desktop **1** to the frame by using firstly minifix bolt **C** and then M6 x 35 **A** screws to finish assembly.



Step 11

ASSEMBLY INSTRUCTIONS

Complete assembly process by placing the upper drawer on it's rails after desktop ¹ assembly is finished.



Step 12

